


ScentWave™ Quick Start Guide

For: SWD1004




I can be scheduled to run up to 6 separate Scent Events. An event can be programmed to run on separate days of the week and will use the selected scent level to deliver fragrance to the space.



CHOOSE THE SCENT LEVEL

This controls the scent intensity of the cartridge. There are seven levels, one (1) is low intensity, seven (7) is high intensity.


Start at four (4) and adjust as needed for your space.



ADJUST THE FAN SPEED

This controls the coverage area of the fragrance. The system can effectively cover spaces up to 2000sq.ft.

Start with the knob at the "12:00" position and adjust to fit your space.



SET-UP A SCENT EVENT

The ScentWave uses a Scent Event to schedule the system to run at certain times and on specific days of the week.

Set up Scent Events to run during the busiest times of the day for your space.

Suggested EVENT 1 Settings: Run from 9:00am to 5:00pm, 7 days a week.

For further assistance please contact ScentAir: www.scentair.com

North America: 1.704.504.2320 | Europe: +33(0)5 62 57 63 20 | Asia: +852 356 378 42