

SWD1001 QUICK SETUP

The ScentWave SWD1001 can be programmed to run up to 2 separate Events. An event will run every day of the week and use the selected mode and auto intervals to delivery fragrance to the space.

It is recommended to setup the system to run for 10 hours a day. The suggested settings for the SWD1001 system are the MASTER POWER set to "TIMER" with EVENT 1 preset to run from 9:00am to 5:00pm. The recommended MODE is "AUTO" with the AUTO INTERVALS set to "60S". The fan speed should be set to 50%.

1. SET MASTER POWER TO "TIMER":

The system will utilize the timer to control the time of day to turn the system on and off. Press SET until EVENT 1 ON TIME flashes and press + or - to adjust.

On Time determines when the event will start each day. Off Time determines when the event will end each day.

2. SET THE MODE TO "AUTO":

The system will run the programmed event settings and deliver fragrance using intervals. Selecting AUTO will use the AUTO INTERVAL settings to control the fragrance intensity.

3. CHOOSE THE INTERVAL:

Measured in seconds, this controls the amount of time the cartridge fan will cycle ON and OFF.

There are three (3) options. Start with each switch at "60S". Adjust as need to best fit your space.

4. ADJUST THE VOLUME:

This controls the coverage area of the fragrance based on the speed of the cartridge fan. The system can effectively cover spaces up to 2000sq.ft.

Start with the knob at the "12:00" position and adjust after an hour.

